



## MAG2000

### SET UP INSTRUCTIONS

Your Shockwatch MAG2000 units may arrive in an activated condition, that is, with the red indicator showing.

**To set the units for use**, follow this procedure:

1. Affix the unit to the desired location using adhesive or screws in the holes provided.
2. To unlock the cover, use the round black ring shaped “key” that accompanied your shipment. Place the ring key over the MAG 2000 cover inserting the 4 prongs through the 4 slots in the cover.
3. Press firmly down on the ring key and while holding the downward pressure, turn the key slightly to the left (counter-clockwise) until the cover loosens. Excessive torque is not needed.
4. Remove the key, then grasp the cover and turn it left (counter-clockwise) as far as possible.
5. Lift the cover off and put the red indicator magnet back to the center position (red side up).

**NOTE:** Be careful to keep finger prints and debris off of the insides of the unit, and off of the bottom of the indicator magnet

6. Place the clear cover back on the unit. Press down and turn right (clockwise) as far as possible until the cover locks into place.

**To reset the MAG2000**, the clear cover must be removed and the red indicator magnet must be manually returned to the center position. Simply repeat steps 2 thru 5.